



Ride Custom Systems Fitting Check List

This comprehensive tools and materials check-list will ensure you have all materials and tools necessary for a successful in-field fitting, including modifications, of a Ride Custom Cushion and/or Back support.

Ride Custom Cushion:

- Cushion
- Owners manual and warranty information.
- Consumer contract
- Black and silver sharpie pens
- 2 gauges
- Electric knife
- Cat or dog shedding blade for cushion modifications
- 2" hook Velcro to attach cushion to wheelchair.

Ride Custom Back

- Back support and hardware.
- White wax china marker, silver sharpie, or similar to mark new trim lines on back shell.
- Owners manual and warranty information.
- 10 mm and 13 mm end wrenches.
- 5 mm and 4 mm allen wrenches.
- #2 Phillips screwdriver.
- High quality masking tape
- Jig saw with ~ 10 point per inch wood cutting blade to modify trim lines.
- De-burring tool or a fine metal/wood rasp/file, radius on one side.
- Drill with variety of bits including a 19/64" drill bit.
- Propane torch or a very hot high quality heat gun to heat and flex plastic shells for shape modification.
- Sewing machine for alterations to back support cover if significant reduction of back size is accomplished. Modified inner shells with cover can be returned under the 90 day guaranteed fit program for alterations.

Note: It is advisable to have a complete set of shape capture tools on-hand should a re-do prove necessary. Please call Ride Customer Service for RA information and instructions for a re-do.



Ride Designs®
a branch of Aspen Seating, LLC

4211-G South Natches Court
Sheridan, Colorado 80110

toll-free 866.781.1633
phone 303.781.1633
fax 303.781.1722