

Owner's Handbook:

Ride™ Corbac™ Adjustable Back Support



Ride Designs®
a branch of Aspen Seating, LLC

8100 SouthPark Way
Littleton, Colorado 80120 USA

toll-free (U.S. Only): 866.781.1633
phone: 303.781.1633
www.ridedesigns.com

Supplier: This manual must be transferred to the end user of this product as it contains important information for proper use of this product.

User: Carefully read this entire manual prior to using this product and keep for future reference.

Intended Use and Installation Instructions

Intended Use

Your Ride Designs® Corbac™ is an Adjustable Wheelchair Back Support that has been carefully constructed to meet your posture and skin integrity needs and has been designed to be mounted to multiple wheelchair styles and sizes to aid in supporting and positioning of wheelchair users.

Weight Capacity

Maximum user weight is 250 pounds (113kg).



General Product Safety

Safe application of this product depends upon your good judgment and common sense, as well as that of your provider, caregiver, and/or healthcare professional, and your attentiveness in following the cautions, notes, and instructions in this manual.

NOTE: We have compiled this manual from the latest specifications and product information available at the time of publication. We reserve the right to make changes as they become necessary. Any changes to our products may cause slight variations between the illustrations and explanations in this manual and the product you have purchased.

⚠ **WARNING:** All Ride Designs support surfaces are designed to help reduce the incidence of pressure sores. However, no back support can completely eliminate sitting pressure or prevent pressure sores. The Ride Corbac is not a substitute for good skin care including proper diet, cleanliness, and regular pressure relief techniques.

CAUTION: Failure to heed cautions may result in damage to your product.

⚠ Please read this instruction manual before using this product.

⚠ All Ride Designs support surfaces are designed to help reduce the incidence of pressure sores. However, no back support can completely eliminate sitting pressure or prevent pressure sores. The Ride Corbac is not a substitute for good skin care including proper diet, cleanliness, and regular pressure relief techniques.

⚠ Installation of any back rest on your wheelchair might alter your center of gravity within the wheelchair. A recessed back position might cause the wheelchair to tip backwards, potentially resulting in injury. Always assess the need for anti-tippers or amputee axle adapter brackets to be added to your wheelchair to help increase stability. Similarly, a more forward back position might reduce the forward stability of the wheelchair, increasing risk of tipping forward, with potential for injury.

⚠ Do not use your Corbac without the spacer mesh overlay in place.

⚠ Do not lift the wheelchair by the Corbac.

⚠ Improper placement or securement of the Ride Corbac to your wheelchair may result in injury.

⚠ This product should be installed and fitted by a qualified and competent healthcare professional. Failure to accurately assess and adjust the fit of the Corbac could result in injury to the user.

Installation and Use Instructions

It is recommended that a therapist or authorized Ride Designs supplier conduct the initial fitting of your back support. Your Ride Corbac is designed to enhance core trunk stability by providing posterior and lateral support to the lower trunk, lumbar spine, and pelvis (ie, the core). The Corbac Adjustable Mount uses straps to achieve the initial support for balance and alignment. The thoraco-lumbar-pelvic (TLP) supports provide additional posterior-lateral support and the Corbac's spacer mesh overlay provides a lightweight cushioning support to facilitate moisture vapor transport while reducing shear.

The Corbac consists of four components: 1) the adjustable mount, 2) two thoraco-lumbar-pelvic (TLP) supports, 3) the spacer mesh overlay and 4) four mounting clamps.

Determine appropriate installation instructions

Before installation determine the configuration needed and proceed to the correct section of the handbook:

- ❑ If replacing sling back upholstery on a wheelchair WITHOUT push handles, refer to the section titled "Replace existing sling back upholstery on a wheelchair without push handles."
- ❑ If replacing sling back upholstery on a wheelchair that has back canes with integrated push handles and existing threaded inserts, refer to the section titled "Replace existing sling back upholstery on a wheelchair with push handles and existing threaded inserts."
- ❑ If replacing sling back upholstery on a wheelchair with integrated push handles, but WITHOUT threaded inserts, refer to the section titled "Replace sling back upholstery on a wheelchair that has back canes with integrated push handles but without existing threaded inserts."
- ❑ If installing Corbac over existing sling back upholstery, refer to the section titled "Install Corbac over existing sling back upholstery."


Corbac installation



Replace existing sling back upholstery on a wheelchair without push handles



1. Remove the existing wheelchair back upholstery.
2. Adjust back cane height (if applicable) for desired back support height.
3. Slide the Corbac adjustable mount onto the wheelchair back canes.
 - a. Remove the Corbac adjustable mount from the cardboard packaging. Do not unfold.
 - b. Locate the back cane pockets along the inside of the back panel and under the adjustment straps. Reflective tape identifies the opening of the cane pockets.
 - c. Slide Corbac adjustable mount cane pockets over the wheelchair back canes. (You may need to slightly loosen the adjustable mount straps.)

⚠ Failure to use the back cane pockets can result in the Corbac sliding down the back canes resulting in injury to user.
4. Tighten the adjustment straps slightly. On some rigid model wheelchairs one or more of the bottom adjustment strap(s) may need to be located below the rigidizer bar.
5. Pull down and attach privacy flap to seat sling allowing sufficient slack for the cushion to be placed against the back canes.
6. Install the seat cushion ensuring proper location.
7. Proceed to section titled "Fitting the Corbac."



Replace existing sling back upholstery on a wheelchair with push handles and existing threaded inserts

1. Verify that the Corbac will be used without the original wheelchair back upholstery and that the rear canes are equipped with push handles (A) and threaded inserts (B) as shown in Illustration 1.
2. Remove the Corbac adjustable mount from the cardboard packaging. Do not unfold.
3. Locate large pocket underneath the adjustment straps.
4. Slide the Corbac adjustable mount over the push handles of the wheelchair pushing the handles through holes provided in the inside upper and lateral corners of the large pocket.
5. Align the grommets on the Corbac mount with the original threaded insert on the wheelchair.
6. Insert screw from original wheelchair upholstery through the grommet and into the threaded insert, and tighten securely (Illustration 2).
7. Tighten Corbac Mount tension straps lightly. On some rigid model wheelchairs, the bottom strap(s) may need to be located below the rigidizer bar.
8. Pull down and attach privacy flap to seat sling allowing sufficient slack for a seat cushion to be placed against the back canes.
9. Install seat cushion ensuring proper location.
10. Proceed to section titled "Fitting the Corbac."



Replace sling back upholstery on a wheelchair that has back canes with integrated push handles but without existing threaded inserts

1. Verify that the Corbac will be used without the wheelchair back upholstery and that the rear canes are equipped with push handles but without existing threaded inserts (Illustration 3).
2. Determine the cane diameter at the location where the top of the Corbac height will be positioned.
3. Use the following clamps for your cane diameter:

1" cane	Large clamps without shims
7/8" cane	Large clamps with shims
3/4" cane	Small clamps with shims
4. With the clamp's screw inserts towards the back side of the wheelchair, install the clamps by spreading the clamps over the canes (Illustration 4). Adjust the clamp height to $\frac{3}{4}$ " below the final Corbac height and ensure both clamps are at the same height above the seat rails (Illustration 5). Do not install the screws at this time.
5. Install the Corbac adjustable mount.
 - a. Remove the Corbac adjustable mount from the cardboard packaging and detach spacer fabric overlay. Do not unfold. Locate the large pockets underneath the adjustable straps.
 - b. Slide the Corbac adjustable mount over the wheelchair push handles and clamps, pushing the handles through the holes provided in the inside upper and lateral corners of the large pocket (Illustration 6).
 - c. Align the adjustable mount grommet holes with the clamps and insert the 10-32 screws provided. Adjust the clamp rotations to match the desired curvature of the adjustable mount. Tighten the screws securely (Illustration 7).
6. Tighten straps lightly. On some rigid model wheelchairs, the bottom strap(s) may be located below the rigidizer bar.
7. Pull down and attach the privacy flap to seat allowing sufficient slack for a seat cushion to be placed against the back canes.

8. Install seat cushion ensuring proper location.
9. Proceed to section titled "Fitting the Corbac."

Install Corbac over existing sling back upholstery

1. Leave existing sling back upholstery in place on wheelchair.
2. Install the Corbac adjustable mount.
 - a. Remove the Corbac adjustable mount from the cardboard packaging. Do not unfold.
 - b. Locate the large pocket underneath the adjustment straps.
 - c. Slide the Corbac adjustable mount over the wheelchair's sling back upholstery. Ensure the existing sling upholstery is inserted into the large pocket. (You may need to slightly loosen the straps.)
 - d. Tighten straps lightly. On some rigid model wheelchairs, the bottom strap(s) may be located below the rigidizer bar.
4. Pull down and attach privacy flap to seat sling allowing sufficient slack for a seat cushion to be placed against the back canes.
5. Install seat cushion ensuring proper location.
6. Proceed to section titled "Fitting the Corbac."



Fitting the Corbac

1. Transfer onto wheelchair.
2. Adjust straps on mount for optimal balance and trunk alignment (Illustration 8).
3. Adjust thoraco-lumbar-pelvic (TLP) supports (Illustration 9).
 - a. Lean forward and place TLP supports (tips pointing inward) against your trunk at desired location in the lumbar-sacral region.
 - b. Lean back to attach wedges to the front surface of the adjustable mount via the hook and loop fastener.
 - c. The TLP supports can be moved up/down, in/out, and rotated. In some instances, they may extend beyond the width of the wheelchair frame and can be trimmed.
 - d. Continue to make adjustments to the TLP supports until the desired posture and comfort is achieved.
4. Install the spacer mesh overlay (Illustration 10).
 - a. Lean forward and pull the spacer mesh overlay over the adjustable mount and TLP supports.
 - b. Attach the hook fastener at the inside bottom/front of overlay to the loop fastener on the front of the adjustable mount.
 - c. Lean back and attach the four loop fastener straps of the overlay to the back of the adjustable mount straps.
 - d. Pull the spacer mesh overlay back flap over the adjustable mount's straps. Loop fastener strips on the back flap will affix to the back side of the adjustable mount straps.
 - e. Readjustment of TLP supports may be necessary once overlay is in place. Simply remove overlay, adjust position of the TLP supports, and re-install the overlay.








Initial wearing schedule

Prior to prolonged sitting, it is advisable to use your Ride Corbac for a short period of time and visually check any area that contacts the back support. Any reddened area should fade within 10-30 minutes. Contact your doctor or therapist if redness persists for greater than 30 minutes. As long as skin inspections do not show red areas persisting more than 30 minutes, you are safe to continue use. Skin checks should be made no less than daily, even after skin tolerance is established. Continue to perform routine intermittent pressure relief techniques (forward lean) as advised by your healthcare professional.

⚠ WARNING: If any redness associated with the use of the Corbac persists for greater than 30 minutes, cease using and contact your therapist or doctor immediately.

Follow-up

It is recommended to have your seated posture and skin integrity checked by your healthcare professional at least annually, or whenever you experience a change in your weight, posture, or general condition that could impact your ability to sit safely, comfortably, and functionally.

Laundry Care Symbols	
	Machine wash warm water (40° C)
	Do not bleach
	Drip dry
	Do not dry clean
	Do not iron

Care and Maintenance of Your Ride Corbac

Cleaning the Corbac spacer mesh overlay

- Remove the spacer mesh overlay from the Corbac.
- Attach hook/loop fasteners to each other. Place in a zipper bag
- Machine or hand wash in warm water (regular detergent/no bleach).
- Hang dry.

Cleaning the Corbac adjustable mount

Using a damp cloth or mild disinfectant, clean the privacy flap, TLP supports, and base components as needed.

CAUTION: Do not clean your Corbac with isopropyl alcohol or any other chemical solvents.

Motor vehicle safety

⚠ RISK OF INJURY: The Corbac has NOT been dynamically tested for use in a motor vehicle. Do not rely on a Corbac for safe impact support in a motor vehicle. Serious injury or death could occur during a motor vehicle accident without proper Original Equipment Manufacturer vehicle safety features being utilized.

1. Always transfer out of your Corbac and into Original Equipment Manufacturer vehicle seat and restraints for motor vehicle travel.

Maintenance

The Corbac and attachments should be routinely checked every 6 months minimum for loose, missing or damaged hardware and proper functionality. Inspect and tighten all components according to this manual. Contact your authorized Ride Designs supplier regarding any damaged or missing components.

⚠ Do NOT continue to use your product with any loose, missing or damaged components.

Product Life

The maximum intended usage of this product is four years.

Reuse

⚠ RISK OF INJURY: Consult an authorized Ride Designs dealer before transferring to another user. Do NOT use product if any damage is found.

Disposal

♻ Recycle components and materials per local, state, and national regulations.

Warranty Policy

Your Ride Designs® Corbac™ Adjustable Back Support has been carefully constructed to meet your posture and skin integrity needs. This Limited Warranty is effective for 24 months from the date of delivery to the original purchaser. If any defect in material or workmanship is found, Ride Designs will repair or replace the component, at our discretion. This limited warranty does not cover daily wear and tear or damage that is a result of mishandling, misuse, neglect, or not following the care and maintenance instructions.

Claims and repairs should be processed through your nearest authorized Ride Designs rehab technology supplier. A copy of the Bill of Sale issued to the purchaser of the product may be required prior to processing a warranty claim.



The Ride Corbac back support works best when used with a complementary Ride Designs Cushion

The **Ride Forward Cushion** is most appropriate for people with mild to moderate risk for skin breakdown.

Achieve a high level of skin protection and functional performance with the **Ride Java Cushion** (only the Ride Custom Cushion can provide a higher level of protection and support).



For people at higher risk for skin breakdown, and/or more challenging postural control needs, the **Ride Custom Cushion** is the ultimate in postural support and skin care. It is specifically contoured to support a person's unique size, shape, posture and functional requirements. Available in US only.

More information on the full line of Ride Designs cushion options is available at www.ridedesigns.com.

Installation Notes

Patents: www.ridedesigns.com/patents
© 2015, Ride Designs. 090-005-B



MDSS GmbH
Schiffgraben 41
30175 Hannover, Germany